

TPS25940EVM-635: Evaluation Module for TPS25940X

This user's guide describes the evaluation module (EVM) for the Texas instruments TPS25940X devices. TPS25940X devices are eFuse with true reverse blocking for power MUX that operates from 2.7 V to 18 V, the device has integrated back-to-back FETs with programmable undervoltage, overvoltage, reverse-voltage, overcurrent and in-rush current protection features.

NOTE: The TPS25940-Q1 and TPS25940L-Q1 devices can also be evaluated on this EVM by replacing the TPS25940ARVC (U1) and TPS25940LRVC (U2) with the TPS25940AQRVC and TPS25940LQRVC.

Contents

1	Introduction	2
	1.1 EVM Features	2
	1.2 EVM Applications	2
2	Description	2
3	Schematic.....	3
4	General Configurations	4
	4.1 Physical Access.....	4
	4.2 Test Equipment	5
	4.3 Test Setup	6
	4.4 Test Procedures	7
5	EVM Assembly Drawings and Layout Guidelines.....	12
6	Bill of Materials (BOM).....	14

List of Figures

1	TPS25940XEVM Schematic	3
2	EVM Test Setup	6
3	V _{OUT} Ramp Up Time for CH1	9
4	V _{OUT} Ramp Up Time for CH2	9
5	J4 = LO Current Limit Test Auto Retry (CH1)	11
6	J9 = "No Jumper" Current Limit Test with Latch (CH2)	11
7	Top Side Placement	12
8	Top Side Routing Layer	12
9	Bottom Side Routing Layer	13

List of Tables

1	TPS25940X EVM Options and Default Setting	2
2	Input and Output Connector Functionality.....	4
3	Test Points Description	4
4	Jumper and LED Descriptions	4
5	EVM Configuration Setting	5
6	Operational Range Setting for VIN1, VIN2 = 12 V, 5 V and 3.3 V	7
7	PWR635 DMM Readings at Different Test Points	7
8	PWR635 Oscilloscope Setting for Ramp Up Voltage Test.....	8

9	PWR635 Oscilloscope Settings for Current Limit Test	10
10	PWR635 Jumper Setting for Current Limits	10
11	TPS25940EVM-635 Bill of Material	14

1 Introduction

The TPS25940XEVM allows reference circuit evaluation of TI's TPS25940X devices. The TPS25940X devices are available with both latched and auto-retry operation.

1.1 EVM Features

- 2.7-V to 18.0-V (TYP) operation
 - CH1 rising input voltage turn-on threshold – 10.5 V (TYP)
 - CH1 falling input voltage turn-off threshold – 9.7 V (TYP)
 - CH2 rising input voltage turn-on threshold – 2.3 V (TYP)
 - CH2 falling input voltage turn-off threshold – 2.1 V (TYP)
- 0.6-A to 5.0-A programmable current limit
- Programmable undervoltage lockout, overvoltage
- Programmable V_{OUT} slew rate
- Latched-off TPS25940LRVC (CH2)
- Auto-Retry TPS25940ARVC (CH1)
- Pushbutton RESET signal
- On-board transorb for overvoltage input protection
- Schottky diode at output to minimize negative spike when load is removed

1.2 EVM Applications

- Solid state drives and hard disk drives
- PCIe, RAID, and NIC cards
- USB power switch
- Industrial
 - PLCs
 - Solid-state relays and FAN control

2 Description

The TPS25940EVM-635 enables full evaluation of the TPS25940X devices. The EVM supports two versions (Auto-retry and Latched) of the devices on two Channels (CH1 and CH2, respectively). Input power is applied at J3 (CH1) and J8 (CH2), while J2 (CH1)/J7 (CH2) provide the output connection to the load, refer to the schematic in [Figure 1](#), and test setup in [Figure 2](#).

D5/C1 (CH1), D9/C7 (CH2) provides input protection for TPS25940X (U1 and U2, respectively) while D4/C2/C3/C4 (CH1), D8/C8/C9/C10 (CH2) provides output protection.

Table 1. TPS25940X EVM Options and Default Setting

Part Number	EVM Function	V_{IN} Range	UVLO		OVP	Current Limit			Fault Response	
			CH1	CH2		LO setting	No Jumper	HI Setting	CH1	CH2
TPS25940EVM-635	Current Limiter with DEVSLP	2.7 V–18 V	10.5 V	2.3 V (internal)	16.5 V	3.6 A	2.1 A	5.3 A	Auto-retry	Latched

S1 allows U1 and S2 allows U2 to be RESET or disabled. A power good (PG) indicator is provided by D3, D6 for CH1 and CH2, respectively, and circuit faults can be observed with D2 and D6. Scaled channel current can be monitored at TP11 and TP22 with a scale factor of 0.842 V/A.

3 Schematic

Figure 1 shows the EVM schematic.




Figure 1. TPS25940EVM Schematic

4 General Configurations

The following sections describe physical access, test equipment, test setup, and test procedures for the EVM.

4.1 Physical Access

Table 2 lists the TPS25940EVM-635 input and output connector functionality. Table 3 describes the test point availability and Table 4 describes the jumper functionality.

Table 2. Input and Output Connector Functionality

Connector	Label	Description
J3	CH1	VIN1(+), GND(-)
J2		VOUT1(+),GND(-)
J8	CH2	VIN2(+), GND(-)
J7		VOUT2(+),GND(-)

Table 3. Test Points Description

Channel	Test Points	Label	Description
CH1	TP3	VIN1	CH1 Input power supply to the EVM
	TP8	EN_UV1	CH1 Active high enable and under voltage input
	TP5	OVP1	CH1, Active high overvoltage input (>16.5V)
	TP11	IMON1	CH1 Current monitor. Load current = 1.187 x voltage on TP11
	TP2	VOUT1	CH1 Output from the EVM
	TP9	PG1	CH1 Power good test point
	TP4	FLTb1	CH1, Fault test point
	TP12	GND	GND
	TP13	GND	GND
	TP14	GND	GND
CH2	TP15	VIN2	CH2 Input power supply to the EVM
	TP17	EN_UV2	CH2 Active high enable and under voltage input
	TP18	OVP2	CH2, Active high overvoltage input
	TP22	IMON2	CH2 Current monitor. Load current = 1.187 x voltage on TP22
	TP16	VOUT2	CH2 Output from the EVM
	TP21	PG2	CH2 Power good test point
	TP20	FLTb2	CH2, Fault test point
	TP24	GND	GND
	TP25	GND	GND
	TP26	GND	GND

Table 4. Jumper and LED Descriptions

Jumper	Label	Description
J1	J1	Priority MUX Setting (applicable to TPS25942EVM-635)
J4	LO - HI	CH2 Current Setting
J5	J5	PG1 and FLTb1 setting
J6	J6	DEVSLP1 Setting
J9	LO - HI	CH2 Current Setting
J10	J10	DEVSLP2 Setting
D2 (Red)	D2	CH1 circuit fault indicator. LED turns on when the internal MOSFET is disabled due to a fault condition such as over load , short circuit, under voltage etc.

Table 4. Jumper and LED Descriptions (continued)

Jumper	Label	Description
D3 (Green)	D3	CH1 Power good indicator. LED turns on when the voltage at TP2(VOUT1) is more than 11 V
D6 (Red)	D6	CH2 circuit fault indicator. LED turns on when the internal MOSFET is disabled due to a fault condition such as overload , short circuit, undervoltage, and so forth.
D7(Green)	D9	CH2 Power good indicator. LED turns on when the voltage at TP2(VOUT1) is more than 11 V

Use [Table 5](#) to set the EVM in different configurations in order to achieve the desired functionality from the TPS25940EVM-635.

Table 5. EVM Configuration Setting

Jumper Location		E-fuse with DevSleep
J4	1-2	Install jumper at this location for 5.3 A current Limit for VIN1
	2-3	Install jumper at this location for 3.6 A current Limit for VIN1
	OPEN	If no jumper is installed default current limit is 2.1 A for VIN1
J9	1-2	Install jumper at this location for 5.3 A current Limit for VIN2
	2-3	Install jumper at this location for 3.6 A current Limit for VIN2
	OPEN	If no jumper is installed default current limit is 2.1 A for VIN2
J5	1-2	OPEN
	3-4	
J1	1-2	Install Jumper to get PG1 from VOUT1
	2-3	OPEN
J6	1-2	OPEN
	2-3	
J10	1-2	OPEN
	2-3	

4.2 Test Equipment

This section describes the power supply, meter, oscilloscope, and loads for testing this EVM.

4.2.1 Power Supplies

One adjustable power supply: 0-V to 20-V output, 0-A to 6-A output current limit.

4.2.2 Meters

One DMM minimum needed and may require more if simultaneous measurements are needed.

4.2.3 Oscilloscope

A DPO2024 or Lecroy 424 oscilloscope or equivalent, three 10X voltage probes, and a DC current probe.

4.2.4 Loads

One resistive load or equivalent which take up to 6 ADC load at 12 V and capable to do the output short.

4.3 Test Setup

Figure 2 shows a typical test setup for the TPS25940XEV. Connect J3/J8 to the power supply and J2/J7 to the load.




Figure 2. EVM Test Setup

4.4 Test Procedures

Use the following steps for the test procedure:

1. The operational voltage range of the two rails VIN1 and VIN2 can be adjusted by changing a few resistor settings, as listed in [Table 6](#).

Table 6. Operational Range Setting for VIN1, VIN2 = 12 V, 5 V and 3.3 V

VIN Operational Range	Rail: VIN1 or VIN2	R9	R13	R11	R22	R26
12 V: 10.5 V to 16 V (Default)	VIN1	16.9k	32.4k	47k		
5 V: 4.6 V to 5.7 V	VIN1	23.2k	105k	137k		
3.3 V: 3 V to 3.8 V	VIN1	48.7k	187k	237k		
2.3 V to 15.5 V (Default)	VIN2				NoPoP	32.4k
5 V: 4.6 V to 5.7 V	VIN2				130k	100k
3.3 V: 3 V to 3.8 V	VIN2				237k	169k

2. Turn on the power supply and set the power supply voltage to 12 V.
3. Turn off the power supply. Hook up CH1 and CH2 of the PWR635 assembly as shown in [Figure 2](#).
4. Ensure that the output load is disabled and the power supply is set properly for the design under test (DUT). Connect the negative probe of DMM to TP12 or TP25 (GND).
5. Turn on the power supply, **only 1 channel at a time**. Verify that the voltages shown in [Table 7](#) are obtained.

Table 7. PWR635 DMM Readings at Different Test Points

Voltage test on (CH1)	Measured Voltage Reading	Voltage tested on (CH2)	Measured Voltage Reading
VIN1 (TP3)	12 ±0.3 VDC	VIN2 (TP15)	12 ±0.3 VDC
EN_UV1 (TP8)	1.13 ±0.1 VDC	EN_UV2 (TP17)	12 ±1 VDC
OVP1 (TP5)	0.742 ±0.1 VDC	OVP2 (TP18)	0.742 ±0.1 VDC
IMON1 (TP11)	32.9 mV ±5 mV VDC	IMON2 (TP22)	32.6 mV ±5 mV VDC
VOUT1 (TP2)	12 ±0.3 VDC	VOUT2 (TP16)	12 ±0.3 VDC
PG1 (TP9)	2.40 ±0.2 VDC	PG2 (TP21)	2.4 ±0.2 VDC
FLTb1 (TP4)	10.51 ±0.5 VDC	FLTb2 (TP20)	10.5 ±0.5 VDC

4.4.1 Preliminary Tests

4.4.1.1 For CH1 (J3-J2)

- With the power supply set to 12 V on CH1, verify that the green PG LED (D3) is on. Press the EVM RST switch, S1 and verify that the voltage at VOUT1 (TP2) starts falling slowly below 12 V and that the green PG LED (D3) turns off and FLTb1 red LED (D2) turns ON. Release S1.
- Reduce the input voltage on VIN1 and monitor VOUT1, Verify that VOUT1 (TP2) starts falling and is fully turned off when VIN1 (TP3) reaches 9.5 V (± 0.5 V). Verify that the PG1 green LED (D3) turns off and FLTb1 red LED (D2) turns ON.
- Increase the input voltage on VIN1 and monitor VOUT1, Verify that VOUT1 (TP2) starts increasing and is fully turned off when VIN1 (TP3) reaches 16.5 V (± 1 V). Verify that the PG1 green LED (D3) turns off and FLTb1 red LED (D2) turns ON.

4.4.1.2 For CH2 (J8-J7)

- With the power supply set to 12 V on CH2, verify that the green PG LED (D7) is on. Depress the EVM RST switch, S2 and verify that the voltage at VOUT2 (TP16) starts falling slowly below 12 V and that the green PG LED (D7) turns off and red FLTb2 LED (D6) turns ON. Release S2.
- Reduce the input voltage on VIN2 and monitor VOUT2, verify that VOUT2 (TP16) starts falling and is fully turned off when VIN2 (TP15) reaches 2.1 V (± 0.3 V). Verify that the PG2 green LED (D7) turns off and FLTb2 red LED (D6) turns ON.
- Increase the input voltage on VIN2 and monitor VOUT2, verify that VOUT2 (TP16) starts increasing and is fully turned off when VIN2 (TP15) reaches 15.5 V (± 1 V). Verify that the PG2 green LED (D7) turns off and FLTb2 red LED (D6) turns ON.
- Turn off both the power supplies.

4.4.1.3 Ramp up Time Test (CH1 and CH2)

- Verify ramp up time (CH1 and CH2, **with only 1 channel powered at a time**). Set up the oscilloscope as shown in [Table 8](#).

Table 8. PWR635 Oscilloscope Setting for Ramp Up Voltage Test

Oscilloscope setting	CH1 Probe Points	CH2 Probe Points
Channel 1 = 5 V/div	TP2 = VOUT1	TP16 = VOUT2
Channel 2 = 5 V/div	TP3 = VIN1	TP15 = VIN2
Channel 3 = 2 V/div	TP8 = EN/UVLO1	TP17 = EN/UVLO2
Trigger source = Channel 1		
Trigger level = 6.0 ± 0.5 V		
Trigger polarity = Positive		
Trigger Mode = Single Sequence		
Time base = 1 ms/div		

- Set the output load at 100 Ω on CH1 and then enable the load. Turn on the power supply, Press the EVM RST switch, S1 and release verify that VOUT1 (TP2) ramps up as [Figure 3](#) illustrates.




Figure 3. V_{OUT} Ramp Up Time for CH1

- Set the output load at 100 Ω on CH2 and then enable the load. Turn on the power supply, Press the EVM RST switch, S2 and release verify that VOUT2 (TP16) ramps up as [Figure 4](#) shows.




Figure 4. V_{OUT} Ramp Up Time for CH2

4.4.1.4 Current Limit Tests

- Verify all three current limits (CH1 and CH2, **with only 1 channel powered at a time**) and verify the latch and auto-retry feature. Setup the oscilloscope as shown in [Table 9](#).

Table 9. PWR635 Oscilloscope Settings for Current Limit Test

Oscilloscope setting	CH1 Probe Points	CH2 Probe Points
Channel 1 = 5 V/div	TP2 = VOUT1	TP16 = VOUT2
Channel 2 = 5 V/div	TP3 = VIN1	TP15 = VIN2
Channel 4 = 2 A/div	Input current into J3 +ve wire	Input current into J8 +ve wire
Trigger source = Channel 4		
Trigger level = 1.0 ±0.2 A		
Trigger polarity = +ve		
Trigger Mode	AUTO	Single Sequence
Time base	40 ms/div	100 ms/div

NOTE: If an electronic load is used, ensure that the output load is set to constant resistance mode and not constant current mode.

NOTE: Measuring Current Limit values on the oscilloscope can easily cause 10% error from anticipated values listed in [Table 10](#).

NOTE: Since the pulse width of current can vary significantly with the VIN ramp rate, which varies from one power supply to another, do **not** worry about matching the pulse widths of [Figure 5](#) and [Figure 6](#).

- The jumper setting for the different current limit test is shown in [Table 10](#).

Table 10. PWR635 Jumper Setting for Current Limits

Jumper Position		Load Current Limit (A)
J4 (CH1)	J9 (CH2)	
HI	HI	5.3
LO	LO	3.6
No Jumper	No Jumper	2.1

- Set the output load at $1.0 \Omega \pm 0.1 \Omega$ on CH1 and then enable the load. Turn on the VIN1 power supply. Verify that the input current is limited as per the setting in Table 10. Verify the device is in auto-retry mode as shown in Figure 5 and FLTb1 RED LED (D2) turns on and off.




Figure 5. J4 = LO Current Limit Test Auto Retry (CH1)

- Set the output load at $1.0 \Omega \pm 0.1 \Omega$ on CH2 and then enable the load. Turn on the VIN2 power supply and verify that the input current is limited as per the setting in Table 10. Also verify the device is in latched-off mode and FLTb1 RED LED (D2) turns ON as shown in Figure 6.




Figure 6. J9 = “No Jumper” Current Limit Test with Latch (CH2)

- Set the input power supply to zero volts and disconnect all equipment from the DUT.

5 EVM Assembly Drawings and Layout Guidelines

Figure 7 through Figure 9 show component placement and layout of the EVM.




Figure 7. Top Side Placement




Figure 8. Top Side Routing Layer




Figure 9. Bottom Side Routing Layer

6 Bill of Materials (BOM)

Table 11 lists the BOM for this EVM.

Table 11. TPS25940EVM-635 Bill of Material

Designator	Qty	Value	Description	PackageReference	PartNumber	Manufacturer	Alternate PartNumber	Alternate Manufacturer
!PCB	1		Printed Circuit Board		PWR635	Any	-	-
C1	1	0.1uF	CAP, CERM, 0.1uF, 25V, +/-10%, X7R, 0603	0603	06033C104KAT2A	AVX		
C2, C3, C8, C9	4	4.7uF	CAP, CERM, 4.7uF, 25V, +/-10%, X7R, 1206	1206	C3216X7R1E475K	TDK		
C4, C10	2	330uF	CAP, AL, 330uF, 25V, +/-20%, 0.16 ohm, SMD	HA0	EMZA250ADA331MHA0G	Nippon Chemi-Con		
C5, C11	2	330pF	CAP, CERM, 330pF, 100V, +/-5%, X7R, 0603	0603	06031C331JAT2A	AVX		
C6, C12	2	1000pF	CAP, CERM, 1000pF, 100V, +/-20%, X7R, 0603	0603	06031C102MAT2A	AVX	-	-
C7	1	1uF	CAP, CERM, 1uF, 25V, +/-10%, X5R, 0603	0603	C1608X5R1E105K080AC	TDK		
D1	1	30V	Diode, Schottky, 30V, 0.2A, SOT-23	SOT-23	BAT54C-7-F	Diodes Inc.		
D2, D6	2	Red	LED, Red, SMD	Power TOPLD w/lens	LS E63F-DBFA-1-Z	OSRAM	-	-
D3, D7	2	Green	LED, Green, SMD	Power TOPLD w/lens	LT E63C-CADB-35-L-Z	OSRAM	-	-
D4, D8	2	20V	Diode, Schottky, 20V, 3A, SMA	SMA	B320A-13-F	Diodes Inc.		
D5, D9	2	16V	Diode, TVS, Uni, 16V, 600W, SMB	SMB	SMBJ16A-13-F	Diodes Inc.		
FID1, FID2, FID3	3		Fiducial mark. There is nothing to buy or mount.	Fiducial	N/A	N/A		
H1, H2, H3, H4	4		Bumpon, Cylindrical, 0.312 X 0.200, Black	Black Bumpon	SJ61A1	3M		
J1, J4, J6, J9, J10	5	1x3	Header, TH, 100mil, 1x3, Gold plated, 230 mil above insulator	PBC03SAAN	PBC03SAAN	Sullins Connector Solutions	Equivalent	Any
J2, J3, J7, J8	4		Terminal Block, 2x1, 5.08mm, TH	10.16x15.2x9mm	282841-2	TE Connectivity		
J5	1		Header, TH, 100mil, 2x2, Gold plated, 230 mil above insulator	TSW-102-07-G-D	TSW-102-07-G-D	Samtec, Inc.	Equivalent	Any
LBL1	1		Thermal Transfer Printable Labels, 0.650" W x 0.200" H - 10,000 per roll	PCB Label 0.650"H x 0.200"W	THT-14-423-10	Brady	-	-
Q1	1	30V	MOSFET, N-CH, 30V, 100A, SON 5x6mm	SON 5x6mm	CSD17301Q5A	Texas Instruments	None	None
Q2, Q3	2	60V	MOSFET, N-CH, 60V, 0.31A, SOT-323	SOT-323	2N7002KW	Fairchild Semiconductor		None
R1, R2, R16, R17	4	100k	RES, 100k ohm, 5%, 0.1W, 0603	0603	CRCW0603100KJNEA	Vishay-Dale		
R3, R4, R18, R19, R20	5	475k	RES, 475k ohm, 1%, 0.1W, 0603	0603	CRCW0603475KFKEA	Vishay-Dale	Equivalent	Any
R5	1	10.0k	RES, 10.0k ohm, 1%, 0.1W, 0603	0603	CRCW060310K0FKEA	Vishay-Dale	Equivalent	Any
R6	1	0.1	RES, 0.1 ohm, 1%, 3W, 2512	2512	CRA2512-FZ-R100ELF	Bourns		
R9, R10, R25	3	16.9k	RES, 16.9k ohm, 1%, 0.1W, 0603	0603	CRCW060316K9FKEA	Vishay-Dale	[NoValue], [NoValue], Equivalent	[NoValue], [NoValue], Any
R11, R23	2	47k	RES, 47k ohm, 5%, 0.1W, 0603	0603	CRCW060347K0JNEA	Vishay-Dale		
R12, R27	2	24.9k	RES, 24.9k ohm, 1%, 0.1W, 0603	0603	CRCW060324K9FKEA	Vishay-Dale		
R13, R26	2	32.4k	RES, 32.4k ohm, 1%, 0.1W, 0603	0603	CRCW060332K4FKEA	Vishay-Dale		
R14, R28	2	16.2k	RES, 16.2k ohm, 1%, 0.1W, 0603	0603	CRCW060316K2FKEA	Vishay-Dale		
R15, R24	2	100k	RES, 100k ohm, 1%, 0.1W, 0603	0603	CRCW0603100KFKEA	Vishay-Dale		
R21, R29	2	10k	RES, 10k ohm, 5%, 0.1W, 0603	0603	CRCW060310K0JNEA	Vishay-Dale		
S1, S2	2		Switch, Push Button, SMD	2.9x2x3.9mm SMD	SKRKAEE010	Alps	Equivalent	Any
SH-J1, SH-J4, SH-J9	3	1x2	Shunt, 100mil, Gold plated, Black	Shunt	969102-0000-DA	3M	SNT-100-BK-G	Samtec

Table 11. TPS25940EVM-635 Bill of Material (continued)

Designator	Qty	Value	Description	PackageReference	PartNumber	Manufacturer	Alternate PartNumber	Alternate Manufacturer
TP1, TP4, TP5, TP8, TP9, TP11, TP17, TP18, TP20, TP21, TP22	11	White	Test Point, TH, Multipurpose, White	Keystone5012	5012	Keystone	Equivalent	Any
TP2, TP3, TP15, TP16	4	Red	Test Point, TH, Multipurpose, Red	Keystone5010	5010	Keystone	Equivalent	Any
TP6, TP19, TP23	3	Orange	Test Point, Multipurpose, Orange, TH	Orange Multipurpose Testpoint	5013	Keystone		
TP7	1	White	Test Point, Multipurpose, White, TH	White Multipurpose Testpoint	5012	Keystone		
TP10, TP14, TP26	3	Black	Test Point, TH, Multipurpose, Black	Keystone5011	5011	Keystone	Equivalent	Any
TP12, TP13, TP24, TP25	4	SMT	Test Point, SMT, Compact	Testpoint_Keystone_Compact	5016	Keystone	Equivalent	Any
U1	1		2.7V-18V eFuse with True Reverse Blocking and DevSleep Support for SSDs, RVC0020A	RVC0020A	TPS25940ARVC	Texas Instruments		None
U2	1		2.7V-18V eFuse with True Reverse Blocking and DevSleep Support for SSDs, RVC0020A	RVC0020A	TPS25940LRVC	Texas Instruments		None
R7	0	0.003	RES, 0.003 ohm, 1%, 1W, 2512	2512	73M1R003F	CTS Resistor		
R8	0	32.4k	RES, 32.4k ohm, 1%, 0.1W, 0603	0603	CRCW060332K4FKEA	Vishay-Dale		
R22	0	48.7k	RES, 48.7k ohm, 1%, 0.1W, 0603	0603	CRCW060348K7FKEA	Vishay-Dale		
SH-J5, SH-J6, SH-J10	0	1x2	Shunt, 100mil, Gold plated, Black	Shunt	969102-0000-DA	3M	SNT-100-BK-G	Samtec
	Notes:	Unless otherwise noted in the Alternate PartNumber and/or Alternate Manufacturer columns, all parts may be substituted with equivalents.						

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

Changes from A Revision (June 2016) to B Revision Page

- Changed NOTE in the *Abstract* 1

Changes from Original (June 2014) to A Revision Page

- Document-wide change: TPS25940XEVM-635 to TPS25940EVM-635, where applicable..... 1
- Added NOTE to *Abstract*. 1
- Changed part from TPS25940LRUV to TPS25940LRVC in *EVM Features* list. 2
- Changed part from TPS25940ARUV to TPS25940ARVC in *EVM Features* list. 2
- Modified *Part Number* in the *TPS25940X EVM Options and Default Setting* table..... 2

STANDARD TERMS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, and/or documentation which may be provided together or separately (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms set forth herein. User's acceptance of the EVM is expressly subject to the following terms.
 - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductor products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms that accompany such Software
 - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
 - 2.1 These terms do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
 - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for a nonconforming EVM if (a) the nonconformity was caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI, (b) the nonconformity resulted from User's design, specifications or instructions for such EVMs or improper system design, or (c) User has not paid on time. Testing and other quality control techniques are used to the extent TI deems necessary. TI does not test all parameters of each EVM. User's claims against TI under this Section 2 are void if User fails to notify TI of any apparent defects in the EVMs within ten (10) business days after delivery, or of any hidden defects with ten (10) business days after the defect has been detected.
 - 2.3 TI's sole liability shall be at its option to repair or replace EVMs that fail to conform to the warranty set forth above, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.
3. *Regulatory Notices:*
 - 3.1 *United States*
 - 3.1.1 *Notice applicable to EVMs not FCC-Approved:*

FCC NOTICE: This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.
 - 3.1.2 *For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:*

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210 or RSS-247

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required to follow the instructions set forth by Radio Law of Japan, which includes, but is not limited to, the instructions below with respect to EVMs (which for the avoidance of doubt are stated strictly for convenience and should be verified by User):

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないものご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・インスツルメンツ株式会社
東京都新宿区西新宿 6 丁目 2 4 番 1 号
西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page
電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。 http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page

3.4 *European Union*

3.4.1 *For EVMs subject to EU Directive 2014/30/EU (Electromagnetic Compatibility Directive):*

This is a class A product intended for use in environments other than domestic environments that are connected to a low-voltage power-supply network that supplies buildings used for domestic purposes. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*

6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY MATERIALS PROVIDED WITH THE EVM (INCLUDING, BUT NOT LIMITED TO, REFERENCE DESIGNS AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY EPIDEMIC FAILURE WARRANTY OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.

6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT, REGARDLESS OF WHEN MADE, CONCEIVED OR ACQUIRED.

7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS OR THE USE OF THE EVMS , REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN TWELVE (12) MONTHS AFTER THE EVENT THAT GAVE RISE TO THE CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY USE OF AN EVM PROVIDED HEREUNDER, INCLUDING FROM ANY WARRANTY, INDEMNITY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS, , EXCEED THE TOTAL AMOUNT PAID TO TI BY USER FOR THE PARTICULAR EVM(S) AT ISSUE DURING THE PRIOR TWELVE (12) MONTHS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products (<http://www.ti.com/sc/docs/stdterms.htm>), [evaluation modules](#), and [samples](http://www.ti.com/sc/docs/sampterm.htm) (<http://www.ti.com/sc/docs/sampterm.htm>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2018, Texas Instruments Incorporated